

American Innovations Allegro MX Keyboard Shortcuts

Global Shortcuts			AiDVM			CeCi		
Caps Toggle	<Blue> <Caps Lock>	Toggles caps lock on and off.	Accept Selection in Drop-down List	<Enter>	Press <Enter> to accept selection in a drop-down list in DVM <i>Options</i> window.	Open View Menu	<Alt> <V>	Press <Alt> <V> to open <i>View</i> window.
Display Backlight	<Orange> <F3>	Toggles backlight on and off.	Move Cursor to Sample Rate Field	<S>	Press <S> to move cursor to Sample Rate field in DVM <i>Options</i> window.	Open Remark Window	<Alt> <R>	Press <Alt> <R> to open <i>Remark</i> window.
Display Brighten/Dim	<Orange> <F4> <Orange> <F5>	Brightens or dims the screen display. Select ORANGE shift key then F4 to dim, or F5 to brighten.	Display Graph Remarks	<Tab>	Press <Tab> to move cursor to <i>Save</i> button in DVM graph window, then press <Enter> to display graph remarks window.	Navigating Misc Tab in Options	 <V> <W> <D>	Press to enable or disable <i>Beep on every Reading</i> . Press <V> to move cursor to <i>Voltage level</i> . Press <W> to enable or disable <i>Beep when overwrite existing data</i> . Press <D> to enable or disable <i>Enable double-click detection</i> .
Move Between Fields and Buttons	<TAB>	Move cursor between fields and buttons. Left tab arrow moves cursor backward; right tab arrow moves cursor forward.		<Enter>	Press <Enter> in graph remarks window to add a new line; press <Tab> to move cursor to <i>Ok</i> or <i>Cancel</i> and then press <Enter>.	Navigating File Tab in Options	<A> <I> <R>	Press <A> to enable or disable <i>Autosave</i> . Press <I> to move cursor to <i>Interval (minutes)</i> . Press <R> to enable or disable <i>Retain Skipped records in Skip mode</i> .
Move from One Tab to Another	<Ctrl> <TAB>	Move from one tab to another in a window with multiple tab pages.	CeCi			Navigating GPS Tab in Options	<C> <S> <G>	Press <C> to enable or disable <i>Clear GPS Location After</i> . Press <S> to move cursor to <i>Seconds Without Updates</i> . Press <G> to move cursor to <i>GPS Display Format</i> .
Open Drop-down List	<Alt> <Down Arrow>	Press <Alt> and down arrow to open drop-down list.	New	<Ctrl> <N>	Create new survey file.	Navigating Graph Tab in Options	<G> <U> <L> <W>	Press <G> to enable or disable <i>Show Graph</i> . With <i>Show Graph</i> enabled: Press <U> to move cursor to <i>Upper Value</i> . Press <L> to move cursor to <i>Lower Value</i> . Press <W> to move cursor to <i>Width</i> .
Touchscreen	<Blue> <TS>	Enable or disable touchscreen.	Open	<Ctrl> <O>	Open <i>File Open</i> window.	Navigating Colors Tab in Options	<E> <Tab> <Up/Down Arrows> <Home/End Arrows>	Press <E> to enable or disable <i>Enable Color</i> . With <i>Enable Color</i> enabled: • Press <Tab> to move cursor between field selection list and color grid. • Press <Up/Down or Home/End arrows> to move cursor in field selection list or color grid.
Task Manager	<Blue> <Esc>	Open <i>Task Manager</i> .	Save	<Ctrl> <S>	Save survey file.	Navigating Open and Save As Windows	<Tab> <Up/Down Arrows>	Press <Tab> to move cursor between fields. Press <Up/Down Arrows> to navigate list of files.
Close Window	<Esc>	Close an open window.	Flag Marker	<F>	Insert flag marker in flagged mode.			
Windows Start Menu		Open <i>Start</i> menu.	Reset Flag Count	<Ctrl> <F>	Reset flag count.			
AiDVM			Gap Marker	<G>	Insert gap marker in flagged mode.			
Graph	<G> or <Alt> <G>	Open graph.	Capture Reading	<Enter>	Capture a reading.			
Copy / Paste	<Ctrl> <C> <Ctrl> <V>	Copy current DVM reading. Paste DVM reading in an open file, such as Excel.	First Record	<Ctrl> <Blue> <Home>	Move cursor to first record.			
Option Window	<N> or <Alt> <N>	Open <i>Options</i> window.	Last Record	<Ctrl> <Blue> <End>	Move cursor to last record.			
Voltage Range	<Ctrl> <Up Arrow> <Ctrl> <Down Arrow> <U> or <Alt> <U>	Increase voltage range. Decrease voltage range. Select autoranging.	Go To	<Ctrl> <G>	Open <i>Go To Location</i> window.			
VDC Test Function	<D> or <Alt> <D>	Select Vdc test function.	Skip	<Ctrl> <K>	Open <i>Skip Distance</i> window in Fixed Increment mode.			
VAC Test Function	<A> or <Alt> <A>	Select Vac test function.	Insert Record	<Ctrl> <Ins>	Insert new record.			
Amp Test Function	<M> or <Alt> <M>	Select Amp test function.	Delete Record	<Ctrl> 	Delete selected record.			
Ohm Test Function	<O> or <Alt> <O>	Select Ohm test function.	Skip/Lock/Normal	<Ctrl> <Z>	Toggles <i>Skip</i> , <i>Lock</i> , and <i>Normal</i> in Fixed Increment mode.			
Diode Test Function	<I> or <Alt> <I>	Select Diode test function.	Remark	<Alt> <R>	Open remark window.			
Move Cursor Between Fields	<TAB>	Press <TAB> to move cursor from one field to another in DVM <i>Options</i> window.	Pause/Resume	<Ctrl> <P>	Pause or resume timed readings.			
Move Cursor in Drop-down List	<Up/Down Arrows>	Press up/down arrows to move cursor up and down in a drop-down list in DVM <i>Options</i> window.	Test Point Information	<Ctrl> <T>	Open <i>Test Point Information</i> window.			
Enable or Disable Autoranging	<A>	Press <A> to enable or disable autorange option in DVM <i>Options</i> window.	Open File Menu	<Alt> <F>	Press <Alt> <F> to open <i>File</i> menu.			
			Open Move Menu	<Alt> <M>	Press <Alt> <M> to open <i>Move</i> menu.			

American Innovations Allegro MX Keyboard Shortcuts

Annual / Periodic Survey

Open	<Ctrl> <O>	Open <i>File Open</i> window.
Save	<Ctrl> <S>	Save survey file.
Copy, Cut, Paste	<Ctrl> <C>	Copy selection to clipboard.
	<Ctrl> <X>	Remove selection and copy to clipboard.
	<Ctrl> <V>	Paste content from clipboard.
Select Data in a Field	<Shift> <Blue> <Home>	Select data from the current cursor location to the end of the field.
	<Shift> <Blue> <End>	Select data from the current cursor location to the beginning of the field.
Undo	<Ctrl> <Z>	Undo last change.
Next Page / Previous Page	<Ctrl> <Down Arrow>	Display next page of a multi-page site.
	<Ctrl> <Up Arrow>	Display previous page of a multi-page site.
Next Site / Previous Site	<Shift> <Down Arrow>	Display next site.
	<Shift> <Up Arrow>	Display previous site.
Record GPS Coordinates	<Ctrl> <G>	Records GPS coordinates when cursor is in reading field.
Insert GPS Coordinates	<Ctrl> <I>	Inserts GPS coordinates when cursor is in reading field.
Capture Reading	<Enter>	Capture a reading. Options include: <ul style="list-style-type: none"> • Select reading field and press <Enter> to activate digital voltmeter. Press <Enter> again to capture reading. • Select timed reading field and press <Enter> to set up, start, stop, or cancel timed reading mode.
Navigate Information and Reading Fields	<Alt> <U>	Move cursor between information and reading fields.
Open File Menu	<Alt> <F>	Open <i>File</i> menu.
Open Edit Menu	<Alt> <E>	Open <i>Edit</i> menu.
Open View Menu	<Alt> <V>	Open <i>View</i> menu.
Cancel/Apply Changes	<Esc>/<Cancel> and <Enter>/<OK>	<i>Cancel changes:</i> press <Esc> or move cursor to <Cancel> button and press <Enter>. <i>Apply changes:</i> press <Enter> when in a drop-down list or move cursor to <OK> and then press <Enter>.
Move Cursor in Drop-down List	<Up/Down Arrows>	Press up/down arrows to move cursor in a drop-down list.

DCVG

New	<Ctrl> <N>	Create new survey file.
Open	<Ctrl> <O>	Open <i>File Open</i> window.
Save	<Ctrl> <S>	Save survey file.
Flag Marker	<F>	Insert flag marker in flagged mode.
Reset Flag Count	<Ctrl> <F>	Reset flag count.
Gap Marker	<G>	Insert gap marker in flagged mode.
Capture Reading	<Enter>	Capture a reading.
First Record	<Ctrl> <Blue> <Home>	Move cursor to first record.
Last Record	<Ctrl> <Blue> <End>	Move cursor to last record.
Go To	<Ctrl> <G>	Open <i>Go To Location</i> window.
Skip	<Ctrl> <K>	Open <i>Skip Distance</i> window in fixed increment mode.
Insert Record	<Ctrl> <Ins>	Insert new record.
Delete Record	<Ctrl> 	Delete record.
Remark	<Alt> <R>	Open <i>remark</i> window.
Test Point Information	<Ctrl> <T>	Open <i>Test Point Information</i> window.

GPS Status

Navigating GPS Status Window	<Tab>	Press <Tab> or <Up/Down Arrows> to move cursor between fields.
	<Enter> <Up/Down Arrows>	Press <Enter> to open or close a drop-down list. Press <Up/Down Arrows> to navigate options in drop-down list and then press <Enter> to select an option.
Enable/Disable Read PPS from Internal GPS	<P>	Press <P> to enable or disable <i>Read PPS from Internal GPS</i> .
Apply / Cancel Changes	<Ok> / <Cancel>	Press <Ok> to apply changes or <Cancel> to cancel changes.
Navigating GPS Status Window	<Tab>	Press <Tab> or <Up/Down Arrows> to move cursor between fields.
	<Enter>	Press <Enter> to open or close a drop-down list. Press <Up/Down Arrows> to navigate options in drop-down list and then press <Enter> to select an option.
	<Enter> <Up/Down Arrows>	Press <Up/Down Arrows> to navigate list of files.