


Allegro QX Keyboard Shortcuts

Keyboard shortcuts for the Allegro QX version 6.1. These are the default shortcuts and could change if Personal Buttons are modified in Allegro Settings. Many shortcuts only work when the cursor is in a certain field or tab.

Global Shortcuts

Start Menu		Open the Windows Start menu.
Home Screen	<Orange> 	Displays the Home Screen.
Help Menu	<Orange> <F1>	Display Help menu with a list of general key combinations, including using the camera, taking a screen capture, or viewing the battery status.
Orange Key Lock	<Orange> <Orange> or <Blue> <Orange>	Locks the Orange key in the On position. Press <Orange> again to unlock.
Caps Lock	<Shift> <Shift> or <Blue> <Shift>	Toggle caps lock on and off.
Screen Capture	<Orange> <R>	Capture the screen as an image.
Touchscreen	<Blue> <Esc>	Enable or disable touchscreen.
Task Manager	<Blue> <Esc> or <Orange> <T>	Open <i>Task Manager</i> .
Function Keys	<Blue> <F1-F6>	Activates keys F7 through F12
Display Backlight	<Orange> <F3>	Toggle backlight on and off.
Display Brighten/Dim	<Orange> <F4> or <Orange> <Up Arrow> <Orange> <F5> or <Orange> <Down Arrow>	Brighten the screen display. Dim the screen display
Volume	<Orange> <Right Arrow> <Orange> <Left Arrow>	Increase volume sound Decrease volume sounds
Move Among Fields/Buttons	<TAB> <Up Arrow> <Down Arrow> <Left Arrow> <Right Arrow> <Blue> <Down Arrow> <Blue> <Up Arrow> <ENTER> <Blue> <Left Arrow> <Blue> <Right Arrow>	Move cursor between fields and buttons. Left tab arrow moves cursor backward; right tab arrow moves cursor forward. Move cursor within a selected field. Depending on the field, may also move cursor to the next/previous field or button. Page Down Page Up Select or press the current field or button. Home. Moves to beginning of the current line. End. Moves to end of the current line.
Select Data in a Field	<Shift> <Left Arrow> <Shift> <Right Arrow>	Select the previous character in the field. Select the next character in the field

Global Shortcuts (cont.)

Copy, Cut, Paste	<Ctrl> <C> <Ctrl> <X> <Ctrl> <V>	Copy selection to clipboard. Remove selection and copy to clipboard. Paste content from clipboard.
Move from One Tab to Another	<Ctrl> <TAB>	Move from one tab to another in a window with multiple tab pages.
Drop-down	<Alt> <Down Arrow>	Open drop-down list.
Close Window	<Esc>	Close an open window.

AiDVM Shortcuts

Graph	<G> or <Alt> <G>	Open graph.
Copy / Paste	<Ctrl> <C> <Ctrl> <V>	Copy current DVM reading. Paste DVM reading in an open file, such as Excel.
Option Window	<N> or <Alt> <N>	Open <i>Options</i> window.
Voltage Range	<Ctrl> <Up Arrow> <Ctrl> <Down Arrow> <U> or <Alt> <U>	Increase voltage range. Decrease voltage range. Select autoranging.
VDC Test Function	<D> or <Alt> <D>	Select Vdc test function.
VAC Test Function	<A> or <Alt> <A>	Select Vac test function.
DC Amp	<Ctrl> <D>	Select DC Amp test function.
AC Amp	<Ctrl> <A>	Select AC Amp test function.
AC mA Test Function	<M> or <Alt> <M>	Select Amp test function.
Autoranging	<A>	Enable or disable autorange option in DVM <i>Options</i> window.
Move Cursor to Sample Rate Field	<S>	Move cursor to Sample Rate field in DVM <i>Options</i> window.
Graph Remarks	<Tab> <Enter> <Enter>	Press <Tab> to move cursor to <i>Save</i> button in DVM graph window, then press <Enter> to display graph remarks window. Press <Enter> in graph remarks window to add a new line.

CECI Shortcuts

New	<Ctrl> <N>	Create new survey file.
Open	<Ctrl> <O>	Open <i>File Open</i> window.
Save	<Ctrl> <S>	Save survey file.
Flag Marker	<F>	Insert flag marker in flagged mode.
Reset Flag Count	<Ctrl> <F>	Reset flag count.
Gap Marker	<G>	Insert gap marker in flagged mode.
Capture Reading	<Enter>	Capture a reading.
Go To	<Ctrl> <G>	Open <i>Go To Location</i> window.
Skip	<Ctrl> <K>	Open <i>Skip Distance</i> window in Fixed Increment mode.
Insert Record	<Ctrl> <Ins> <F2>	Insert new record. Display the Insert Record menu if in Flagged Mode.
Delete Record	<Ctrl> 	Delete selected record.
Skip/Lock/Normal	<Ctrl> <Z> or <F3>	Toggles <i>Skip</i> , <i>Lock</i> , and <i>Normal</i> in Fixed Increment mode.
Remark	<Alt> <R> or <F4>	Open remark window.
Pause/Resume	<Ctrl> <P> or <F5>	Pause/resume timed readings.
Test Point Information	<Ctrl> <T>	Open <i>Test Point Information</i> window.
File Menu	<Alt> <F>	Open <i>File</i> menu.
Move Menu	<Alt> <M>	Open <i>Move</i> menu.
View Menu	<Alt> <V>	Open <i>View</i> window.
Remark Window	<Alt> <R>	Open <i>Remark</i> window.
Navigating Misc Tab in Options	 <V> <W> <D>	Enable or disable <i>Beep on every Reading</i> . Move cursor to <i>Voltage level</i> . Enable or disable <i>Beep when overwrite existing data</i> . Enable or disable <i>Enable double-click detection</i> .

Allegro QX Keyboard Shortcuts

Keyboard shortcuts for the Allegro QX version 6.1. These are the default shortcuts and could change if Personal Buttons are modified in Allegro Settings. Many shortcuts only work when the cursor is in a certain field or tab.

CECI Shortcuts (cont.)

Navigating File Tab in Options	<A>	Enable or disable <i>Autosave</i> .
	<I>	Move cursor to <i>Interval (minutes)</i> .
	<R>	Enable or disable <i>Retain Skipped records in Skip mode</i> .
Navigating GPS Tab in Options	<C>	Enable or disable <i>Clear GPS Location After</i> .
	<S>	Move cursor to <i>Seconds Without Updates</i> .
	<G>	Move cursor to <i>GPS Display Format</i> .
Navigating Graph Tab in Options	<G>	Enable or disable <i>Show Graph</i> . With <i>Show Graph</i> enabled:
	<U>	Move cursor to <i>Upper Value</i> .
	<L>	Move cursor to <i>Lower Value</i> .
	<W>	Move cursor to <i>Width</i> .
Navigating Colors Tab in Options	<E>	Enable or disable <i>Enable Color</i> . With <i>Enable Color</i> enabled:
	<Tab>	<ul style="list-style-type: none"> Move cursor between field selection list and color grid. Move cursor in field selection list or color grid.
	<Up/Down/Left/Right Arrows>	

Periodic Survey Shortcuts

Open	<Ctrl> <O>	Open <i>File Open</i> window.
Save	<Ctrl> <S>	Save survey file.
Undo	<Ctrl> <Z>	Undo last change.
Next Page / Previous Page	<Ctrl> <Down Arrow> <Ctrl> <Up Arrow>	Display next page of a site. Display previous page of a site.
Next Site / Previous Site	<Shift> <Down Arrow> <Shift> <Up Arrow>	Display next site. Display previous site.
Find	<Ctrl> <F>	Initiate a Find.
Find Next	<Ctrl> <N>	Find the next record that matches the Find criteria.
Find Previous	<Ctrl> <P>	Find the previous record that matches the Find criteria.
Record GPS Coordinates	<Ctrl> <G> or <F4>	Records GPS coordinates when cursor is in reading field.
Insert GPS Coordinates	<Ctrl> <I> or <F5>	Inserts GPS coordinates when cursor is in reading field.

AiDVM Shortcuts

Capture Reading	<Enter>	<p>In a <i>reading field</i>: Capture a reading.</p> <p>1 <Enter> to activate digital voltmeter.</p> <p>2 <Enter> again to capture reading.</p> <p>In a <i>timed reading field</i>: Set up, start, stop, or cancel timed reading mode.</p>
Navigate Information and Reading Fields	<Alt> <U>	Move cursor between information and reading fields.
File Menu	<Alt> <F>	Open <i>File</i> menu.
Edit Menu	<Alt> <E>	Open <i>Edit</i> menu.
View Menu	<Alt> <V>	Open <i>View</i> menu.

DCVG Shortcuts

New	<Ctrl> <N>	Create new survey file.
Open	<Ctrl> <O>	Open <i>File Open</i> window.
Save	<Ctrl> <S>	Save survey file.
Flag Marker	<F>	Insert flag marker in flagged mode.
Reset Flag Count	<Ctrl> <F>	Reset flag count.
Gap Marker	<G>	Insert gap marker in flagged mode.
Capture Reading	<Enter>	Capture a reading.
Go To	<Ctrl> <G>	Open <i>Go To Location</i> window.
Skip	<Ctrl> <K>	Open <i>Skip Distance</i> window in fixed increment mode.
Insert Record	<Ctrl> <Ins>	Insert new record.
Delete Record	<Ctrl> 	Delete record.
Remark	<Alt> <R>	Open <i>remark</i> window.
Test Point Information	<Ctrl> <T>	Open <i>Test Point Information</i> window.

GPS Status Shortcuts

Open Options	<O>	Open Options.
Enable/Disable Read PPS from Internal GPS	<P>	Enable or disable <i>Read PPS from Internal GPS</i> .

